


CRL8TS Remote Control

SPECIFICATION and INSTRUCTION SHEET



DESCRIPTION: One Ceiling Fan & Light, 3 Speed Touch-Screen Remote Control with Learn Receiver

ELECTRICAL SPECS: 120 Volts, 60 Hertz, Fan 1.0 amp, Light Rating 190W (max.) Incandescent or Halogen, 5 Wire Installation

www.fanimation.com for more information

IMPORTANT: YOU MUST SET YOUR CEILING FAN TO HIGH SPEED AND LIGHT KIT (IF ANY) TO THE ON POSITION BEFORE OPERATING YOUR REMOTE CONTROL.

NOTE: If fan or supply wires are different colors than indicated, have this unit installed by a qualified electrician.

⚠ WARNING

To avoid possible electrical shock, be sure electricity is turned off at the main fuse box before wiring.

NOTE: If you are not sure if the outlet box is grounded, contact a licensed electrician for advise, as it must be grounded for safe operation.

INSTALLATION INSTRUCTIONS:







- Ceiling fan must be set at HIGH speed and light kit (if any) at the ON position by pulling the chain switch after installation.
- Install Receiver in the Hanger Bracket:
 - Slide remote Receiver into the Hanger Bracket (Figure 1).
 - Connect wires as indicated: (Figure 2)
 - Green Hanger Bracket and Hanger Ball wires to BARE (ground) wire.
 - BLACK Receiver Unit wire (AC IN L) to BLACK supply wire.
 - WHITE Receiver Unit wire (AC IN N) to WHITE supply wire.
 - WHITE Receiver Unit wire (TO MOTOR N) to WHITE fan wire.
 - BLACK Receiver Unit wire (TO MOTOR L) to BLACK fan wire.
 - BLUE Receiver Unit wire (FOR LIGHT DOWN) to BLUE light wire.
 - Position all connected wires and receiver antenna to allow installation of ceiling canopy.
 - Using canopy screws threaded into the hanger bracket reinstall ceiling canopy.
 - Restore electrical power



LEARN MODE PROCESS:

- Control and receiver have been factory programmed. If replacing the transmitter or receiver, the learn mode process will need to be used.
- After installing the unit and restoring power to your fan, open the battery cover (with batteries, DC1.5V/AAA 4pcs, installed) and press and hold the "LEARNING BUTTON" 1~3seconds with a ball-point pen or similar object. FAN will turn off and then turn to medium speed and light on, which indicates that the learning process has completed.

IMPORTANT: You must press the "LEARNING BUTTON" within 60 seconds of restoring power to the fan. Remote does not need to be re-learned when replacing the battery.
- If light kit has CFL bulbs, please slide the "light dimmer function select switch" to on/off position. If installed incandescent light bulbs onto ceiling fan, please slide the "light dimmer function select switch" to dimmer position.
- Please note, the remote can learn multiple receivers.



REMOTE FUNCTIONS:

-  : Touch and release immediately to turn fan on or off
-  : Touch and release immediately to turn change fan speeds low/medium/high
-  : Touch to select run time desired—from 1 to 12 hours. Fan will turn off after selected time duration.
-  : Touch and release immediately to turn light on or off (CFL) Touch and release this key to brighten light to the desired level (Incandescent)
-  : If light is on, touch and release immediately and light will turn off after 3 minutes
-  : If light is off, touch and release immediately and light will turn on. After 3 minutes, light will turn off.



⚠ WARNING

Check to see that all connections are tight, including ground, and that no bare wire is visible at the wire connectors, except for the ground wire. Do not operate fan until the blades is in place. Noise and fan damage could result.



10983 Bennett Parkway
Zionsville, IN 46077
(888) 567-2055 • FAX (866) 482-5215
Outside U.S. call (317) 733-4113
Visit Our Website @ www.fanimation.com

Copyright 2009 Fanimation
2009/11